













APPLICATIONS

VAG® ADS230 Software used with ADC219 Cable

APPLICATION CHART

			
Volkswagen® Amarok (2H) * 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Caddy (2K) * 2003 to 2009	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Caddy (2C) * 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Eos (1F) 2005 to 2009	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Eos (1F) 2009 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Golf 5 / Jetta / Bora*(1K) 2006 to 2009	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Golf 6 / Jetta / Bora* (5K) 2009 to 2012	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Passat USA (NM) 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Polo (6R) * 2009 to 2012	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Scirocco (16) * 2008 to 2009	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Scirocco (16) * 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Sharan (7N) * 2010 onwards	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Tiguan (5N) 2007 to 2009	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen Tiguan (5N) 2010 onwards	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Touran (1T1 and 1T2) * 2006 to 2010	ADC250 or ADC251 + ADC219	Smart Dongle	
Volkswagen® Touran II (1T3) * 2011 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	

APPLICATION CHART

			
Volkswagen® Transporter T6 (7E) * 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Škoda® Fabia II Facelift (54) * 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Škoda® Octavia II (1Z) * 2006 to 2009	ADC250 or ADC251 + ADC219	Smart Dongle	
Škoda® Octavia II (1Z) * 2009 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Škoda® Rapid (NH) * 2012 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Škoda® Superb II (3T) * 2008 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Škoda® Yeti (5L) * 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Seat® Alhambra (7N) * 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Seat® Cordoba (6L) * 2005 to 2009	ADC250 or ADC251 + ADC219	Smart Dongle	
Seat® Ibiza (6J) * 2009 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Seat® Ibiza (6J) * 2014 onwards	ADC250 or ADC251 + ADC219	Smart Dongle	
Seat® Leon (1P) * 2005 to 2009	ADC250 or ADC251 + ADC219	Smart Dongle	
Seat® Leon (1P) * 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	
Seat® Toledo (5P) * 2005 to 2009	ADC250 or ADC251 + ADC219	Smart Dongle	
Seat® Toledo (5P) * 2010 to 2013	ADC250 or ADC251 + ADC219	Smart Dongle	

* Relevant to Mexico or Central American regions.

Notes: Due to the number of cluster variations fitted to VAG® group vehicles, AD cannot guarantee 100% coverage for ADC219 / ADS230 in a lost key situation for the vehicles listed in the application list.

The cable has been designed for advanced auto locksmiths who have a good working technical knowledge of removing, disassembling and re-fitting instrument clusters from vehicles.

Important note: To prevent damage to the Smart Dongle, ensure that the ignition is turned off when connecting the tester to the vehicle.

Please visit the **Advanced Diagnostics website** to see the training video procedure.