Drawer Slide MDF Tray

Mounting Instructions

- 1) On a flat surface, place the padded palm rest of your keyboard drawer down on a flat surface.
- 2) Install both the left and right drawer slides using the $3/16 \times 1/2$ " screws provided as illustrated in the diagram.
- 3) On the underside of the table where you want to mount your new keyboard drawer; using a pencil, draw a line 3 inches (76mm) from the front edge of your desk or table.
- 4) Place a mark on the line where you want the center of the keyboard drawer to be located.
- 5) From this center mark location, measure and mark a distance of 9-7/8 inches (251mm) on both the left and right hand sides of the center mark.

- 6. Using a 1/16 inch diameter drill bit, drill (2) screw pilot holes for the left hand and right hand sides of your keyboard drawer.
- 7. Using $3/16 \times 1/2$ " screws provided, install the keyboard drawer to the underside of the table using the two pilot screw holes.
- 8. Drill six additional screw pilot holes using the mounting brackets of your Keyboard drawer as a template or guide.
- 9. Install the remaining screws in the screw pilot holes you just drilled.

