

## Barn Owl House Assembly Instructions

Included

### 34 Screws

**Front Panel** – Large entrance hole located top front, two rails on inside

**Back Panel** – Smallest panel, solid, no holes, two rails on inside

**Roof** – Largest panel with shaped front and sides, two rails on inside

**Floor** – large panel with corners removed, two rails on inside

**Left Side Panel** – Three holes located top rear, two rails on inside

**Right Side Panel** – Two panels actually. See diagram below.

**Wood Chips** - 3 bags

- 1.) Stand the front panel and the left side panel on a flat surface. Attach the front panel to the left side with screws provided and pre-drilled holes. Make sure vent holes on the left side panel are to the top rear. Make sure the edges of the two panels are flush with each other. The tops should be flush as well. This will be important when it's time mount the roof. If you are on a flat surface, the bottoms should take care of themselves.
- 2.) Spin the unit around 180 degrees and attach the back panel to the left side panel, using screws provided and pre-drilled holes. Again, make sure the edges of these two panels are flush with each other.
- 3.) Spin the unit around 90 degrees in order to attach the two right side panels. These two panels are beveled in order to fit tightly together. The bottom right panel will become your clean out door. (The "L" hook attached to the rear panel will function to lock the clean out door closed). The top right panel will have the vent holes to the rear. Attach the bottom right panel first, with one screw on each side, and the pre-drilled holes. These two screws will act as hinges for this panel to swing open for clean out. Keep those edges flush. Attach the top right panel, using the screws provided and the pre-drilled holes. Again, flush edges!
- 4.) Open the clean out panel in order to slide the floor into place. The slats on the floor will be on the inside of the house. They will help keep the eggs from rolling around. Slide the floor into place and attach with screws provided through two pre-drilled holes each on the front panel, left side panel and rear panel. Close and lock the clean out panel.
- 5.) Attach the roof, using screws provided and pre-drilled holes. That should do it. Congratulations!

