



Dear Customer,

Thank you for selecting quality and authenticity for your design environment. We hope you enjoy your purchase!

Instructions – Replacement Seat Part

Your new seat is a modern version of the same plywood seats used on the Model 61 of decades past. The technology has not changed much but the way the seat attaches to the frame has changed.

You have now received two sets of screws: a set of four wood screws and a set of two machine thread screws.



If your stool is manufactured prior to 2010, your stool will have four mounting holes in the top of the frame and will use the wood screws. **IMPORTANT!!!** Before final assembly, please test the length of the wood screws for correct fit by inserting them into their holes. The screw tips should protrude no further than 2 cm (0.78") past the wood frame. If they protrude more than this, you must use shorter screws otherwise you risk puncturing the leather (and more) when they are assembled and sat in.

If the wood screws are at or less than 2cm, proceed and tighten with a Phillips head driver.

If your stool was manufactured in 2010 or later (and has two mounting holes instead of four) you will use the machine screw and tighten with a hex key / wrench.

If you have any question, do not hesitate to email us at info@erikbuch.com

Proudly MADE IN DENMARK