



Backyard Flower Blank **INSTRUCTIONS**



1. Use a hammer and chisel to separate the petals.



2. Heat the flower blank and texture it with a cross-peen or ball-peen hammer.



2. Shape the petals in a cupping tool or swage block.



3. Taper a piece of 1/4" round rod and curl or shape it as your stem



4. Drill a hole in the petals



5. Put everything together, and you have finished your flower!

There many flower styles that can be made
from Backyard Flower Blanks!

If you have any questions regarding your flower
blanks, please contact us:

mail@kensiron.com or 320-746-8161

Visit our website at: <http://kensiron.com>