



Rapid/Quick Knee Tongs INSTRUCTIONS

Due to the more intermediate nature of these tongs and the various different ways they can be assembled, our instructions here will be very minimal. We **highly recommend** watching our **YouTube** video which goes over three of the many ways these tongs can be put together.

Search “Quick Knee Tongs Instructional Video”

or go to: <https://www.youtube.com/watch?v=XNaPEBfQIy0>



1. Decide which type of tongs will work best for your material/project.



2. Forge the jaws and reins



3. Drill a hole to fit your rivet.



4. Rivet together



5. Make final adjustments



Enjoy your finished tongs!

If you have any questions regarding Quick Tongs, please contact us:

mail@kensiron.com or 320-746-8161

Visit our website at: <http://kensiron.com>