



# Rapid/Quick Bolt Tongs

## INSTRUCTIONS



1. Heat the ends of the Quick Bolt Tong blanks. Clamp in a vise and split using a sharp hot chisel



(Should look like this)



2. Shape the jaw on the anvil. They can be square,



or make them round by using the horn of the anvil.



3. Draw out the reins.



4. Drill a hole to fit your rivet and rivet both blanks together.

**You have finished!**

There many jaw styles that can be made from Quick Bolt Tongs Blanks!

If you have any questions regarding Quick Tongs, please contact us:

[mail@kensiron.com](mailto:mail@kensiron.com) or 320-746-8161

Visit our website at: <http://kensiron.com>

