



Rapid/Quick Scroll Tongs **INSTRUCTIONS**



1. Draw out and taper the jaw end on each blank.



2. Make each of your blanks the same.



3. Round up the reins by forging the corners down. You can also clean them up with a sander or flap disc.



4. Drill a hole to fit your rivet in each blank and rivet both halves together.



5. Take one more heat make sure the tips line up and everything is in line.



You have finished!

There many jaw styles that can be made from
Quick Scroll Tongs Blanks!

If you have any questions regarding Quick Tongs, please contact us:

mail@kensiron.com or 320-746-8161

Visit our website at: <http://kensiron.com>