



Rapid/Quick Slot Jaw Tongs **INSTRUCTIONS**

Before you begin, we highly recommend watching our **YouTube** video which goes over these steps in greater detail: Search "Quick Slot Jaw Tongs Instructional Video" or go to: <https://www.youtube.com/watch?v=uJSE92sv9zY>



1. Heat up and draw out the reins.



2. Heat the jaw end and clamp in vise with the groove facing down and lined up with the edge of the vise.



3. Twist counter-clockwise 90-degrees. (It should look like the picture above.)



4. Shape the jaw on the edge of the anvil to thin and curl the end.



5. Sand/file the end of the jaw.



6. Drill a hole to fit your rivet.



7. Rivet together



8. Size to material



Enjoy your finished tongs!

If you have any questions regarding Quick Tongs, please contact us:

mail@kensiron.com or 320-746-8161

Visit our website at: <http://kensiron.com>