

FOLDING PEGS INSTALLATION

Caution:

- The peg attachment is located near the rear brake rotor. DO NOT install immediately after riding as the brake rotor will be hot and could potentially burn you.
- When using footpegs, refer to your bike's user handbook and do not exceed the maximum recommended weight limit for your bike of 325 lbs.
- Avoid touching the brake rotor during installation as the oils on your hand will contaminate the rotor and cause it to squeak when in use.

Included Materials:

- Folding Pegs with Peg Cap (x2)
- Anti-Rotation Bracket (x2)
- Socket Head Screw- M12 x 1.25mm Thread, 20mm long thread (x2)
- Flat washers- 18-8 Stainless Steel for M12 Screw Size, 13mm ID, 2mm OD (x4)
- Keychain Peg Cap Key (x1)

Tools Required:

- 10mm Hex Wrench

Installation Instructions:

- 1** Start with the bike stable and powered off. Locate the peg attachment holes on each side of the frame near the rear wheel.
- 2** Slide one flat washer onto one of the socket head screws then insert the screw into the peg hole from the inside of the frame.
- 3** Hold the washer and bolt in the hole, feed the following components onto the screw in this order:
 - 1 anti-rotation bracket with the single tab positioned under the attachment hole.
 - 1 flat washer.
 - Place the footpeg with the "73" facing up so that the peg folds upwards when not in use. Hand tighten the assembly until the hex wrench is needed.
- 4** Now that all of the components are aligned, use the 10 mm hex wrench to tighten the peg into place.
- 5** Once the peg is fastened, repeat the process for the other footpeg.
- 6** The Keychain Peg Cap Key can be used to remove the peg caps. Insert the end of the key into the slotted part of the cap and rotate counter-clockwise to remove. To install, tighten the peg cap clockwise.

VISIT [SUPPORT.SUPER73.COM](https://support.super73.com) FOR HELP