



WWW.TWOBROS.COM  
167 Via Trevizio Corona, CA 92879 - (800) 211-2767

## Yamaha Zuma 125

Full Exhaust System with Hurricane Canister  
Part # 005-24701-HU



### Parts List

Qty.	Description	Part Number
1	Hurricane Muffler Canister	005-S1RSKULL
1	Header	005-24701H
1	Muffler Clamp	005-R37522-10
1	HARDWARE KIT	005-247-3
2	45mm Springs	005-545
1	Mounting Bracket "V2"	005-247-B2
1	Fender Support Bracket	005-247-FS
2	8mm Flange Nut	005-FN8
1	6x20mm Socket Head Cap Screw	005-SH620
2	M6 Flat Washer (18mm OD)	005-WF6-18
1	10x35mm Black Flange Bolt	005-FB1035B
3	8x25mm Flange Bolt	005-FB825
1	11.5 Aluminum Spacer w/10mm hole	005-S-11-10
1	Rubber Grommet	005-*9307K62
1	Rubber Grommet Sleeve	005-247-24
1	6mm Flange Nut	005-FN6
2	8mm Flat Washer	005-WF8
1	Spring Puller	005-SP

### IMPORTANT - PLEASE READ CAREFULLY


*We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.*

### Installation Instructions


1. Make sure the bike is completely cool before starting the installation. Make sure the bike is secure on a centerstand or ideally a service lift.
2. Remove OEM O2 sensor from head pipe.




3. Remove OEM headpipe by removing the 3 mounting bolts and header nuts keeping rubber grommet in rear fender for re-use.



4. Install TBR muffler mounting bracket using the bolt with the spacer on the top bolt as shown.



5. Mount the fender support with the 6x20mm socket head cap screw and washer through rubber grommet into fender support bracket.



6. Install TBR muffler to TBR header pipe using supplied 45mm springs
7. Install TBR header pipe assembly and mount muffler using the supplied muffler clamp and secure with the supplied flange bolt, nut, and washers on each side of rubber grommet.





WWW.TWOBROS.COM

167 Via Trevizio Corona, CA 92879 - (800) 211-2767

## Yamaha Zuma 125

Full Exhaust System with Hurricane Canister  
Part # 005-24701-HU



Qty.	Description	Part Number
1	Hurricane Muffler Canister	005-S1RSKULL
1	Header	005-24701H
1	Muffler Clamp	005-R37522-10
1	HARDWARE KIT	005-247-3
2	45mm Springs	005-S45
1	Mounting Bracket "V2"	005-247-B2
1	Fender Support Bracket	005-247-FS
2	8mm Flange Nut	005-FN8
1	6x20mm Socket Head Cap Screw	005-SH620
2	M6 Flat Washer (18mm OD)	005-WF6-18
1	10x35mm Black Flange Bolt	005-FB1035B
3	8x25mm Flange Bolt	005-FB825
1	11.5 Aluminum Spacer w/10mm hole	005-S-11-10
1	Rubber Grommet	005-*9307K62
1	Rubber Grommet Sleeve	005-247-24
1	6mm Flange Nut	005-FN6
2	8mm Flat Washer	005-WF8
1	Spring Puller	005-SP

## Installation Instructions

- Re-install the OEM O2 sensor.
- Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.



## Care & Cleaning / Warranty

### Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. For cleaning use a mild spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel.

Carbon Fiber Mufflers: Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the Carbon Fiber sleeve. TBR sells repack kits (TBR part # 005-10038) that include new rivets and repack material as well as a drill bit (#30), making it easy to do yourself. Also, NEVER dyno test your bike with carbon fiber mufflers installed - the intense heat and lack of cooling air can quickly cause the CF material to burn. Two Brothers Racing does not provide a warranty for burned carbon fiber.

Aluminum Mufflers: Use an aluminum or mag wheel polish such as Mother's to restore the bright finish to factory spec.

### Warranty Information

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.