

401 South Grand Ave., Santa Ana, CA 92705 Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

NINJA 650R (06-11)/ VERSYS (08-13)/ ER-6N (09-11) Slip-On Exhaust System with S1R Canister Part # 005-3840405-S1



Parts List

1	S1R Muffler Canister	8" S1R Horizontal
1	S1R Muffler Clamp	Horizontal S1R
1	Ninja 650R Slip-Tube	005-38404S
2	45mm Swivel Hook Spring	005-S45
1	8x16mm Flange Bolt	005-FB816
1	8x35mm Flange Bolt	005-FB835
2	8mm Flange Nut	005-FN8
1	Barrel Clamp	005-27-59MSH
1	Ninja 650R Mounting Bracket	005-142-19
1	Permatex Anti-Seize	031-P09175
1	Power Tip (Installed)	005-P1
1	Spring Puller	005-SP
1	TBR Sticker Kit	015-10212

IMPORTANT - PLEASE READ CAREFULLY

Two Brothers Racing products are intended for closed course competition purposes only.

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a center stand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

- Make sure the bike is completely cool before starting the installation. Make sure the bike is secure on the side stand or ideally a service lift.
- Remove the right side lower fairing to expose the muffler assembly.



Remove the three fasteners on the right side cover.

З.

5.



- 4. Loosen the muffler clamp attaching the OEM muffler to the head pipe.
 - Remove the two muffler mounting bolts and remove the OEM muffler. You will re-use the front muffler mount bolt and the rear flange nut.



Installation Instructions

6. Remove the rubber grommet and inserts from the frame where the stock muffler mounted on the left side.



 Attach supplied muffler mounting bracket to the two rubber mounting supports on right side. Use supplied nut and bolt and previous removed nut and bolt.



 Apply a thin layer of anti-seize on muffler inlet and attach to slip tube with supplied hook springs.



9. Slide the (rubber-lined) muffler clamp over the muffler canister and install on bike using supplied barrel clamp.



 Make all adjustments of slip-on tube rotation and muffler rotation to make sure there is clearance between swingarm/tire and brake bedal when applied.





401 South Grand Ave., Santa Ana, CA 92705 Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

NINJA 650R (06-11)/ VERSYS (08-13)/ ER-6N (09-11) Slip-On Exhaust System with S1R Canister Part # 005-3840405-S1



11. Tighten mounting hardware and clamp on canister then tighten

12. Double check all of your work and tighten all hardware.



- 13. Re-install the lower fairing and side cover.
- 14. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Installation Instructions

Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters every 3,000 miles. Part #005-10038 Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide awaranty for burned canisters.

Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

C		

1	S1R Muffler Canister	8" S1R Horizontal
1	S1R Muffler Clamp	Horizontal S1R
1	Ninja 650R Slip-Tube	005-38404S
2	45mm Swivel Hook Spring	005-S45
1	8x16mm Flange Bolt	005-FB816
1	8x35mm Flange Bolt	005-FB835
2	8mm Flange Nut	005-FN8
1	Barrel Clamp	005-27-59MSH
1	Ninja 650R Mounting Bracket	005-142-19
1	Permatex Anti-Seize	031-P09175
1	Power Tip (Installed)	005-P1
1	Spring Puller	005-SP
1	TBR Sticker Kit	015-10212