



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



CFMOTO
Z-FORCE 800
S1R Slip-On
Part # 005-4090409-S1



IMPORTANT - PLEASE READ CAREFULLY

Two Brothers Racing products are intended for closed course competition purposes only. We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Be sure to save all stock components for possible use later.

****This product has not been tested with all available accessories and some items may cause excessive heat. Excessive heat may cause damage to your vehicle. Two Brothers Racing will not be responsible for damaged parts.**

Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

Installation Instructions

1. Make sure the UTV is completely cool before starting the installation. Make sure the UTV is secure on a level surface and the wheels are chocked to prevent the unit from rolling.
2. Remove the OEM springs from the muffler joint.



3. Remove OEM muffler mounting bolts. These will not be used with TBR system.



4. Slide the muffler back and to the right side to remove.



5. Remove right side muffler mounting bracket.



6. Attach S1R inlet to slip tube using supplied hook springs.



7. Slide OEM mounting bracket over TBR muffler tab on inlet side.



8. Slide tab on outlet side of muffler into OEM bracket.



9. Re-use OEM gasket and springs and attach TBR slip-tube to OEM header pipe.



10. Re-position OEM mounting bracket and secure with OEM bolt.



11. Double check your work and enjoy.
12. Re-check hardware after each use.



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



CFMOTO
Z-FORCE 800
S1R Slip-On
Part # 005-4090409-S1

Care & Cleaning

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters at the first signs of packing material deterioration. Part #005-10038

Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.



Qty.	Description	Part Number
1	17.5" S1R Muffler	-
1	Slip-Tube	005-40904S
2	45mm Spring	005-S45
1	Spring Puller	005-SP