



WWW.TWOBROS.COM
401 S. GRAND AVE., SANTA ANA, CA 92705 - (800) 211-2767

2017 CANAM MAVERICK X3 TURBO

Stainless Steel Slip On Exhaust with S1R
Off Road Canister Part# 005-4720409-S1



1 x	Off Road S1R Stainless Muffler	
1 x	Slip Tube	005-47204S
1 x	Bracket	005-472-B
2 x	Springs	005-S45
2 x	Bolts 8mm	005-SH816
2 x	Nuts 8mm	005-FN8
2 x	Muffler Clamps	005-2C1
1 x	Barrel Clamp	005-27-65MSH
1 x	Spark Arrestor (Pre-Installed)	005-107S
1x	Turndown Tip (Pre Installed)	005-SST1
1 x	Spring Puller	005-SP

IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

WARRANTY


Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

INSTALLATION INSTRUCTIONS

1. Make sure the UTV is completely cool before starting the installation.
2. Remove the OEM exhaust springs.



3. Remove the OEM exhaust mounting bracket bolts and rubber mount isolator.



4. Remove the OEM exhaust.
5. Remove the OEM exhaust gasket.



6. Locate and remove the 2 black nuts located under the storage panel support bracket.



7. Install the TBR bracket under the panel support bracket and secure it using the 2 black nuts.



8. Attach the slip tube to the existing exhaust using the supplied Barrel Clamp.



9. NOTE: Do not fully tighten clamp yet.
10. Install the included TBR muffler.



11. Install the supplied muffler clamps to the TBR bracket.





WWW.TWOBROS.COM
401 S. GRAND AVE., SANTA ANA, CA 92705 - (800) 211-2767

2017 CANAM MAVERICK X3 TURBO

Stainless Steel Slip On Exhaust with S1R
Off Road Canister Part# 005-4720409-S1



1 x	Off Road S1R Stainless Muffer	
1 x	Slip Tube	005-47204S
1 x	Bracket	005-472-B
2 x	Springs	005-S45
2 x	Bolts 8mm	005-SH816
2 x	Nuts 8mm	005-FN8
2 x	Muffer Clamps	005-2C1
1 x	Barrel Clamp	005-27-65MSH
1 x	Spark Arrestor (Pre-Installed)	005-107S
1x	Turndown Tip (Pre Installed)	005-SST1
1 x	Spring Puller	005-SP

INSTALLATION INSTRUCTIONS

12. Install the included springs to secure the muffer to the slip tube.



13. Begin to tighten all bolts and hardware on the exhaust, start from the head and work your way back to the muffer. Be sure the exhaust has clearance and fits properly.
14. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Also, remove any plastic film from the name badge(s) and or canister clamp(s). Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

CARE & CLEANING

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters at the first signs of packing material deterioration. Part #005-10038
Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.