



WWW.TWOBROS.COM

401 S. GRAND AVE., SANTA ANA, CA 92705 - (800) 211-2767

2018 KAWASAKI NINJA 400

S1R Full System Part # 005-50601-S1



BILL OF MATERIALS

1	Muffler	Varies
1	Clamp	Varies
1	Slip Tube	005-50601S
1	Mid-Pipe	
1	8mm Flange Nut	005-FN8
2	45mm Spring	005-S45
1	18mm Spacer	005-S-18
1	8mm x 60mm Bolt	005-SH860
2	58mm Barrel Clamp	005-27-61MSH
1	Spring Puller	005-SP
1	Sticker Kit	015-10212
1	O2 Adapter Kit	005-92-22kit

INSTALLATION INSTRUCTIONS

1. Make sure the motorcycle is completely cool before installation, and make sure it is secure on a stand or service lift.
2. Remove the OEM heat shield by loosening the hose clamp and removing the mounting screw.
3. Remove the OEM muffler and headers.
4. Install the TBR headers using OEM hardware. Then slide the TBR mid-pipe and one of the supplied barrel clamps onto the headers. **(Reference image 1)**
5. Slide the TBR muffler, slip tube and the other supplied barrel clamp onto the mid-pipe **(Reference Image 2)**



6. Using the supplied hardware and clamp, bolt the TBR muffler to the muffler bracket as shown. Be sure to use the included spacer to space out the muffler. **(Reference images 3 & 4)**



7. Install the supplied springs as shown. **(Reference image 5)**
8. Re-install the O2 sensor. **(Reference Image 6)**



9. Once you ensure the exhaust is fitted properly, tighten all hardware and re-install the fairing.

IMPORTANT - PLEASE READ CAREFULLY: We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a center stand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

WARRANTY: Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

10. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicone sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve.

TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters at the first signs of packing material deterioration. Part #005-10038

Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.



BILL OF MATERIALS

1	Muffler	Varies
1	Clamp	Varies
1	Slip Tube	005-50601S
1	Mid-Pipe	
1	8mm Flange Nut	005-FN8
2	45mm Spring	005-S45
1	18mm Spacer	005-S-18
1	8mm x 60mm Bolt	005-SH860
2	58mm Barrel Clamp	005-27-61MSH
1	Spring Puller	005-SP
1	Sticker Kit	015-10212
1	O2 Adapter Kit	005-92-22kit