



Absolute Top Level®

401 South Grand Ave., Santa Ana, CA 92705  
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



## 2004-10 Yamaha RAPTOR 350

V.A.L.E.™ Slip-On Exhaust System with M-7 Aluminum Canister  
Part # 005-1680406V



### IMPORTANT - PLEASE READ CAREFULLY

*We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Be sure to save all stock components for possible use later.*

**\*\*This product has not been tested with all available accessories and some items may cause excessive heat. Excessive heat may cause damage to your vehicle. Two Brothers Racing will not be responsible for damaged parts.**

### Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

### Installation Instructions

1. Make sure the quad is completely cool before starting the installation. Make sure the quad is secure on a level surface and the wheels are chocked to prevent the quad from rolling.
2. Remove the bolt securing the OEM muffler to the frame.
3. Loosen the OEM clamp connecting the slip tube to the header.
4. Carefully remove OEM muffler assembly from quad.
5. Use the supplied 4 (four) 6 x 14mm bolts and split lock washers to loosely attach the X-Lite™ ring to muffler inlet. (See V.A.L.E. Assembly Detail below)
7. Attach muffler canister to frame using the supplied 8x25mm socket head screw and washer. Tighten the bolt securely.
8. Securely tighten the 4 (four) 6 x 14mm hex head bolts of the V.A.L.E. assembly.
9. Securely tighten the supplied barrel clamp.
10. Double check to make sure that all hardware is securely tightened.
11. Before you run the quad, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the quad and enjoy. It is normal for some white smoke to appear the first time you start the quad. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or



V.A.L.E.™ Assembly Detail

6. Place the supplied barrel clamp onto the TBR slip tube and carefully slide TBR muffler assembly onto the OEM header making sure that the TBR slip-tube is fully inserted.

**IMPORTANT:** Make sure that the slip tube is rotated away from the plastics as far as possible. This will prevent possible damage to the plastics due to excessive heat build-up.

### Care & Cleaning

#### Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

**Stainless Header System:** Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

**Titanium Header System:** Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

**Polished Aluminum Canisters:** Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

**Brushed Aluminum Canisters:** Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

**Carbon Fiber Canisters:** Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

**Titanium Mufflers:** For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters at the first signs of packing material deterioration. Part #005-10038 Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

**NEVER** dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.



401 South Grand Ave., Santa Ana, CA 92705  
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



## 2004-10 Yamaha RAPTOR 350

V.A.L.E.™ Slip-On Exhaust System with M-7 Aluminum Canister  
Part # 005-1680406V



005-1680406V



Qty.	Description	Part Number
1	Muffler Canister M-7	005-168-206M
1	S-Bend Tube	005-16801S
1	HARDWARE KIT	005-168-3
2	X-Ring (half)	005-7-2-3
1	Barrel Clamp	005-27-59MSH
1	8mm Flat Washer	005-WF8
1	8x25mm Socket Head Screw	005-SH825
1	5mm Long Handle Ball End Hex Key	005-9-18610
4	6x14mm Socket Head Cap Screw	005-SH614
4	Split Lock Washer	005-WL6
2	TBR Sticker Kit	015-10212
1	Spark Arrestor (Installed)	005-106S

