



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

2006-09 Honda CRF 150F

Complete Stainless/Aluminum Exhaust System with M-6 Canister
Part # 005-1580104M



Parts List

Qty.	Description	Part Number
1	CRF150F M-6 Muffler Canister	005-15801H
1	CRF150F Header	005-158-204
1	HARDWARE KIT	005-158-3
1	Permatex Ultra Black Gasket Maker	031-P22072
2	TBR Script Logo Yellow Decal 4"	015-10208-A

IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

Installation Instructions

1. Make sure the bike is completely cool before starting the installation. Make sure the bike is secure on the sidestand or ideally a rear service stand.
2. Remove the right, rear number plate panel.
3. Remove the stock exhaust system saving OEM hardware for later use.
4. Install the Two Brothers Racing header using OEM hardware. Leave header flange nuts loose for now.
5. Place a bead of the hi-temp sealant on the outside edge of the header that goes into the canister. Slide the Two Brothers Racing canister onto the end of the header. Wipe off the excess sealant that will squeeze out.
6. Attach muffler to subframe using OEM hardware. Leave loose for now.
7. Make sure everything is aligned and tighten all hardware.
8. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After your first ride, recheck all fasteners for tightness.

005-1580104M



Qty.	Description	Part Number
1	CRF150F M-6 Muffler Canister	005-15801H
1	CRF150F Header	005-158-204
1	HARDWARE KIT	005-158-3
1	Permatex Ultra Black Gasket Maker	031-P22072
2	TBR Script Logo Yellow Decal 4"	015-10208-A

Care & Cleaning

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters every 3,000 miles. Part #005-10038

Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.