



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



2008-09 Honda CRF 230F

Stainless Steel Slip-On Exhaust System with M-7 Canister
Part # 005-2820406V



Parts List

Qty.	Description	Part Number
1	Muffler Canister M-7 Aluminum	005-282-206M
1	Stainless Steel Slip On tube	005-28204S
1	HARDWARE KIT	005-282-3
1	X-Ring	005-7-2-2
4	Split Lock Washer	005-WL6
4	6x14mm Socket Head Cap Screw	005-SH614
1	8x25mm Socket Head Cap Screw	005-SH825
1	8x50mm Socket Head Cap Screw	005-SH850
1	5mm Long Handle Ball end hex key	005-9-18610
1	T20 Torx Screw Hex Key	005-9-15820
1	TBR Sticker Kit	015-10212
1	Spark Arrestor (Installed)	005-106S

IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

Installation Instructions

1. Make sure the bike is completely cool before starting the installation. Make sure the bike is secure on a centerstand or ideally a service lift.

2. Remove right side panel.



3. Remove OEM muffler assembly and mid-pipe joint gasket. This will not be re-used.



4. Install TBR muffler to TBR slip-on using the supplied 6x14mm socket head cap screws and lock washers provided. Leave loose for now.



5. Install TBR muffler assembly.



6. Use supplied 8x25mm socket head cap screw for lower frame mount.



7. Use supplied 8x50mm socket head cap screw for upper muffler mount using the OEM washer and nut. Leave loose for now.



8. Align muffler and tighten X-ring bolts.

9. Tighten the mounting bolts.

10. Re-install OEM side panel.

11. Double check to make sure that all hardware is tightened.

12. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



**2008-09 Honda
CRF 230F**

Stainless Steel Slip-On Exhaust System with M-7 Canister
Part # 005-2820406V

005-2760406V



Qty.	Description	Part Number
1	Muffler Canister M-7 Aluminum	005-171-206M
1	Stainless Steel Slip On tube	005-28204S
1	HARDWARE KIT	005-282-3
1	X-Ring	005-7-2-2
4	Split Lock Washer	005-WL6
4	6x14mm Socket Head Cap Screw	005-SH614
1	8x25mm Socket Head Cap Screw	005-SH825
1	8x60mm Socket Head Cap Screw	005-SH860
1	5mm Long Handle Ball end hex key	005-9-18610
1	T20 Torx Screw Hex Key	005-9-15820
1	TBR Sticker Kit	015-10212
1	Spark Arrestor (Installed)	005-106H

Care & Cleaning / Warranty

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. For cleaning use a mild spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel.

Carbon Fiber Mufflers: Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the Carbon Fiber sleeve. TBR sells repack kits (TBR part # 005-10038) that include new rivets and repack material as well as a drill bit (#30), making it easy to do yourself. Also, NEVER dyno test your bike with carbon fiber mufflers installed - the intense heat and lack of cooling air can quickly cause the CF material to burn. Two Brothers Racing does not provide a warranty for burned carbon fiber.

Aluminum Mufflers: Use an aluminum or mag wheel polish such as Mother's to restore the bright finish to factory spec.

Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.