



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



2009 Honda CRF450R

Stainless Steel Slip-on Exhaust System with M-7 Aluminum Canister
Part # 005-2340406V / 005-2340407V



Parts List

Qty.	Description	Part Number
1	CRF450R Muffler Canister M-7 Aluminum	Varies
1	CRF450R Stainless Steel Slip On Tube	005-23404S
1	HARDWARE KIT	005-234-3
2	X-Ring (half)	005-7-2-3
1	8x16mm Flange Bolt	005-FB816
1	8x25mm Flange Bolt	005-FB825
1	5mm Long Handle Ball end hex key	005-9-18610
4	M6 Split Lock Washer	005-WL6
4	6x14mm Socket Head Cap Screw	005-SH614
1	TBR Sticker Kit	005-10212

IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

Installation Instructions

1. Make sure the bike is completely cool before starting the installation. Make sure the bike is secure on a centerstand or ideally a service lift.
2. Remove right side panel.
3. Remove upper OEM muffler mounting bolt.
4. Remove lower OEM muffler mounting bolt.
5. Remove OEM muffler assembly, clamp and gasket.
6. Use the 4 (four) 6x14mm Socket Head Cap Screws and split lock washers to loosely join the slip-tube to the muffler canister. Do not tighten yet.



10. Securely tighten the 4 (four) 6mm x 14mm hex head bolts of the V.A.L.E.™ assembly.

11. Making sure that the V.A.L.E.™ assembly is oriented correctly, securely tighten upper muffler mounting bolt.


12. Reinstall side panel with original hardware.

13. Double check to make sure that all hardware is tightened

14. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Also, remove any plastic film from the name badge(s). Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.



7. Insert slip tube of V.A.L.E.™ muffler assembly into OEM head pipe. This is a slip fit and the gasket and clamp are not used.
8. Attach muffler mounting bracket to mounting tab on subframe using supplied 8x25mm bolt. Leave loose for now.



9. Using the supplied 8x16mm flange bolt, secure muffler assembly mid-pipe bolt. Tighten securely.



Care & Cleaning / Warranty

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. For cleaning use a mild spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel.

Carbon Fiber Mufflers: Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the Carbon Fiber sleeve. TBR sells repack kits (TBR part # 005-10038) that include new rivets and repack material as well as a drill bit (#30), making it easy to do yourself. Also, NEVER dyno test your bike with carbon fiber mufflers installed - the intense heat and lack of cooling air can quickly cause the CF material to burn. Two Brothers Racing does not provide a warranty for burned carbon fiber.

Aluminum Mufflers: Use an aluminum or mag wheel polish such as Mother's to restore the bright finish to factory spec.

Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



**2009 Honda
CRF450R**

Stainless Steel Slip-on Exhaust System with M-7 Aluminum Canister
Part # 005-2340406V / 005-2340407V




005-2340406V

005-2340407V



Qty.	Description	Part Number
1	CRF450R Muffler Canister M-7 Aluminum	005-234-206M
1	CRF450R Stainless Steel Slip On Tube	005-23404S
1	HARDWARE KIT	005-234-3
2	X-Ring (half)	005-7-2-3
1	8x16mm Flange Bolt	005-FB816
1	8x25mm Flange Bolt	005-FB825
1	5mm Long Handle Ball end hex key	005-9-18610
4	M6 Split Lock Washer	005-WL6
4	6x14mm Socket Head Cap Screw	005-SH614
1	TBR Sticker Kit	005-10212
1	Spark Arrestor (Installed)	005-106S



Qty.	Description	Part Number
1	CRF450R Muffler Canister M-7 Aluminum	005-234-207M
1	CRF450R Stainless Steel Slip On Tube	005-23404S
1	HARDWARE KIT	005-234-3
2	X-Ring (half)	005-7-2-3
1	8x16mm Flange Bolt	005-FB816
1	8x25mm Flange Bolt	005-FB825
1	5mm Long Handle Ball end hex key	005-9-18610
4	M6 Split Lock Washer	005-WL6
4	6x14mm Socket Head Cap Screw	005-SH614
1	TBR Sticker Kit	005-10212