



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

Honda CBR150R

V.A.L.E.™ Full Exhaust System with M-2 Exhaust Canister
Part # 005-3490106V-B



Qty.	Description	Part Number
1	Muffler Canister	005-146-206B
1	Canister Clamp with Rubber Liner	005-2C
1	Slip-tube	005-34901S
1	Header pipe	005-34901H
1	X-Ring Kit	005-7-2-3KIT
1	Barrel Clamp	005-27-59MSH
1	8x50mm Socket Head Cap Screw	005-SH850
1	11.5mm Aluminum Spacer	005-S-11
1	8mm Flange Nut	005-FN8
1	TBR Sticker Kit	015-10212

IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

Warranty Information


Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts. Not tested for use with OEM or aftermarket accessories.

Installation Instructions


1. Make sure the bike is completely cool before starting the installation. Make sure the bike is secure on a centerstand or ideally a service lift.
2. Remove right side lower cowl.




3. Remove header flange nuts. Save to re-use later.
4. Remove OEM exhaust assembly removing 2 remaining mounting bolts.



5. Install TBR header pipe using OEM flange nuts.



6. Install TBR slip-tube and supplied barrel clamp.



7. Attach muffler to TBR slip system using the supplied X-ring, 8x20mm socket head cap screws and lock washers that are provided, leave loose for now. Slide rubber lined muffler clamp and barrel clamp on and install to bike.



8. Loosely attach muffler to bike using the 8x50mm bolt, nut, spacer, and install muffler clamp to outside of mount.





Two Brothers Racing
U.S.A.

Absolute Top Level®

401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

Honda CBR150R

V.A.L.E.™ Full Exhaust System with M-2 Exhaust Canister
Part # 005-3490106V-B



Qty.	Description	Part Number
1	Muffler Canister	005-146-206B
1	Canister Clamp with Rubber Liner	005-2C
1	Slip-tube	005-34901S
1	Header pipe	005-34901H
1	X-Ring Kit	005-7-2-3KIT
1	Barrel Clamp	005-27-59MSH
1	8x50mm Socket Head Cap Screw	005-SH850
1	11.5mm Aluminum Spacer	005-S-11
1	8mm Flange Nut	005-FN8
1	TBR Sticker Kit	015-10212

Installation Instructions

- Check for clearance and alignment, then tighten all the bolts in this order: X-ring bolts, muffler mount, and finally barrel clamp.
- Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat



permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

Care & Cleaning / Warranty Information

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters every 3,000 miles. Part #005-10038

Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.