

Mfg: TBR Make: Honda XR50R Year: All Product: Romic Shock Kit



IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance product be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance product please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on the sidestand or ideally a rear service stand during installation. Be sure to save all stock components for possible use later.

Installation Instructions

- 1. Make sure the bike is completely cool before starting the installation.
- 2. Remove the rear/side panel section (including seat).
- 3. Remove the stock rear shock and retain hardware.
- Apply a small amount of grease to the stock bolts. Apply a small amount of grease to the face of the aluminum eyelets on the Romic shock.
- Install the Romic shock with the rebound (red knob) on the top facing out and the compression (blue knob) on the bottom facing out (ref: photo). Torque bolts to 25 ft. lbs. Be sure the shock can move freely but with no side to side play.
- 6. Reinstall the rear/side panel section (including seat)
- 7. Before you run the bike, double check your work.
- 8. Refer to the Romic manual for fine tuning instructions.

Care & Cleaning / Warranty

Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.