



401 South Grand Ave., Santa Ana, CA 92705
 Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

TBR S1 Pro Rear-Stand

Part # 007-007-G, 007-007-K, 007-007-GR, 007-007-R, 007-007-B



Parts List

Qty. Description

1	Left Side Stand Assembly
1	Right Side Stand Assembly
1	Stainless Steel Hoop
1	HARDWARE KIT
4	8x25mm Socket Head Flat Bolt
1	5mm Long Handle Ball End Hex Key

Installation Instructions

1. Remove and identify all parts from packaging.
2. Locate the "T" on the hoop insert to determine the top.



3. Stand the left and right sides up.



4. Insert stand hoop into center of side supports with "T" facing up.



5. Use supplied 8x25mm socket head flat bolts and tighten to 15 ft-lbs.



*Do not force bolts, if you need to, loosen pre-installed bolts to align threaded backing plate correctly. Loosely install all bolts before final tightening.

6. After lifting the stand a couple of times re-tighten all screws.

