



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com



Two Brothers Racing

Pro Complete Handlebar Kit

Suzuki DR-Z70
Part # 191-6-01P



Parts List

Qty.	Description	Part Number
1	Upper Triple Clamp Assembly	Varies
1	Grips (pair)	010-6-03
1	Throttle Assembly	010-6-04
1	Handlebar	010-6-51B
1	Front Brake Lever	010-6-07
1	Front Brake Cable	010-6-08
1	Throttle Cable (for use with stock carburetor)	010-6-11
1	Kill Switch	191-6-06
1	DR-Z70 Choke Plate	191-6-03

Warranty

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the vehicle and exhaust system are completely cool before starting the installation. Also, make sure the vehicle is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

Installation Instructions

1. Make sure the bike is completely cool before starting the installation. Make sure the bike is secure on a centerstand or ideally a service lift.
2. Remove the seat, sidecovers and fuel tank.
3. Remove the stock handlebars, triple clamp, front brake cable and throttle assembly.
4. Disconnect the wires from the On/Off and Start switch. You can locate these wires by following the wire route from the On/Off switch to the throttle. The wires are located on the left side of the frame.
5. Install the TBR upper triple clamp and carefully align the three mounting holes. Fasten the factory 14mm bolts and washers. Be sure that the clamp seats evenly on the three mounting points and tighten in a triangular pattern until the top crown is evenly fastened.
6. Install the handlebars and tighten the TBR riser block cap using the supplied 8x30mm bolts.
7. Install the new throttle, brake lever and cables in the same fashion as they were removed. Follow the factory cable routing. Double check the carburetor and brake cable for proper adjustment and smooth operation.
8. Install the Run/Stop and Start button to handle bar and secure in the original locations.
9. Install the grips, crossbar pad, fuel tank, seat and sidecovers. Double check your work and your ready to go.
10. After your first ride recheck your work again and re-torque all hardware.
11. The triple clamp features a two position riser block. Select the position that best suits your needs.