



ANEMOI VALVE COVER

WATTSHOP
The Relentless Pursuit of Speed

WATTSHOP

The Relentless Pursuit of Speed

Anemoi Valve Cover

Thank you for purchasing a WattShop #Anemoi valve cover. We hope it serves you well in achieving maximum performance in all of your races! Please share your pictures and results on Facebook, Twitter and Instagram using #WattShop.

WATTS IN THE BOX

| No | Part Description | Quantity | Torque |
|----|------------------|----------|--------|
| 1 | Valve Cover | 1 | - |
| 2 | Grub Screw | 1 | - |
| 3 | Foam Padding | 1 | - |
| 4 | | | |
| 5 | | | |

TOOLS REQUIRED

2mm Hex

NOTES

Do not over torque. Pinch tight is sufficient.

INSTALLATION

WattShop valve covers are simple to install, prior to fitting ensure the area where the cover is to be installed is clean from dirt. To fit ensure the grub screw is clear of the valve hole then simply sit over your valve stem. Lightly push down into the rim profile and tighten the grub screw using a 2mm allen key until it pinches up to the valve stem.

Depending on your rim profile you may need to install the 3mm self adhesive backed foam to the underside of the valve cover prior to sitting the cover over your valve stem. Using the foam will cater for any discrepancy between the valve cover profile and the rim profile.

Ensure to install the airfoil in the correct position at the top of the wheel rotation. To do this spin the wheel so the valve is at the top of the rotation then install with the tail of the air foil pointing rearwards.

