



LUXEWALL

WALNUT PANELS

DESCRIPTION:

Discover the elegance of nature combined with modern design through our latest luxury walnut wood panels. Precision-engineered for beauty, stability, and durability, these panels are finished with a hand applied natural oil, adding a luxurious and inviting look to any space. Unique in creation, they feature mesmerizing textures crafted through precision CNC routing, making each panel a one-of-a-kind addition to your walls.

Each box includes three panels, each of which has its own pattern which can be installed in any orientation, allowing you to customize the look of your wall. Ideal for DIY enthusiasts and professional installers alike, our walnut wood panels promise to transform your space with a blend of luxury, creativity, and natural charm.

INSTALL GUIDE:

REQUIRED TOOLS:



Level



Pencil



Measuring Tape



Construction Adhesive



Table Saw

PREPARATION:

- Prior to installation, the wall panels must be acclimated for all high-humidity environments. Allow a minimum of 24-48 hours for panels to acclimate at the location where you are installing them. HVAC must be on with the temperature maintained between 60°-75°F with a relative humidity of 30-55% for at least 7 days prior to installation, as well as during and after installation. We do not recommend installing in bathrooms or any area with excessive moisture or cold temperatures (less than 60 degrees Fahrenheit).

- Turn off power to the installation area prior to working around electrical outlets or wall switches
Remove all nails, accessories, moldings, light switches and electrical outlet covers from the wall where the product is going to be installed.
- Remove all accessories, moldings, and electrical outlets from the wall where the product is going to be installed.
- Make sure that the surface of the wall is flat and even, with any high spots sanded down. 3/8" thick plywood can be installed over drywall if the wall is in poor condition.
- Remove any loose paint or texture with a painter's knife.

INSTALLATION GUIDE:

Installing your new walnut wood wall panels is a straightforward and rewarding process, ensuring your space is transformed with minimal effort.

1. Preparation: Ensure the wall surface is clean, dry, and smooth. For best results, remove any wallpaper and sand down textured surfaces. A primer application may be beneficial for enhancing adhesive bonding.
2. Adhesive Selection: Choose a high-quality construction adhesive suitable for wood and your wall's material. We recommend a strong, instant-grab adhesive to ensure a secure and lasting bond.
3. Layout Planning: Before applying adhesive, it may be helpful to lay out your panels on the floor to finalize your design and determine how to center them. This step helps you visualize the end result and adjust placements as needed. Note that each panel can be oriented in any direction. There is no right or wrong way to orient them. Each box contains 3 panels, each of which is different from one another.
4. Adhesive Application: Apply adhesive to the back of each panel, ensuring that enough adhesive is used to securely attach the panel to the wall.
5. Panel Placement: Start by installing your first panel, working from the ground up. Press firmly across the entire surface for secure adhesion. If your adhesive has a set time, apply pressure according to the manufacturer's instructions. Once you have your first row installed, use a level to ensure that your first row is level before beginning to install the subsequent rows above it.