

Adding adhesive tape to Mount

- Clean the two raised areas of mount with included alcohol pad.
- Allow it to dry completely.
- Pull the clear plastic piece off one of the tape strips and adhere to the raised plastic surface with the white paper tab side up. (see photo) Repeat for second side.
- Clean the surface where the mount is to be applied.
- Remove white paper tab from both sides of the mount and press the mount, tape side down on the prepared surface required for the holster.
- Once the mount is applied to a case or tablet let it sit without the holster installed for 24 hours so adhesive may properly cure.
- Click the Mozee holster into place on the mount.

