

How to install Dual Lock strips to a Mozee Sled

- With the included alcohol wipe, clean the back of the sled and the tablet/case where you plan to install the sled.
- Once the areas are dry, peel the red backing paper off one side of the red strips to expose the adhesive.
- Press the strips with moderate pressure onto the sled approximately in the position shown, then repeat for the second strip.
- Take the remaining red strips off both pieces of adhesive, and position the sled over the cleaned spot of the tablet/case where you want the sled.
- Apply moderate pressure to affix the sled to the case.

(Adhesive will fully cure within 24-48 hours)

