

HEARTLAND USA[®]

HL-2101FR 19" Front Fender Instructions 2008 - 2011 FXCW and FXCWC

2466 E. Fender Ave. Suite B Fullerton CA. 92831
Phone 310-822-2797 Fax 310-634-1271 www.heartlandbiker.com

1. Remove front brake caliper leaving the brake line attached. Then remove the front tire and wheel. Remove the front fender. Place the Axle back in place to align the lower legs.



2. Then Install the NEW Heartland USA fender. Reuse the HD Bolts for the right of the fender. On the left side use the supplied hardware. Place the spacer so that it is even with the legs bolt boss. Bolt hole is not centered in boss. Use *Blue Loctite* on all bolts.

Parts List:

19" Steel Fender
2 pcs. Spacers
2 pcs. 5/16 x 1" NC Chrome Button Head Bolts
2 pcs Chrome Flat Washers

3. Replace Wheel and Tire. reinstall the Brake caliper. Note: all Factory torque Specs. as per HD manual.

