

HEARTLAND USA®

HL-2101FR21 21" Front Fender Instructions 2008 to 2011 HD Rocker - Rocker C / FXCW and FXCW C

1. Remove front brake caliper leaving the brake line attached. Then remove the front tire and wheel. Remove the front fender. Place the Axle back in place to align the lower legs.



2. Then Install the NEW Heartland USA fender.

Note: That the Right side of the fender is Flat and the Left has welded on spacers. Reuse the HD Bolts for the right of the fender. On the left side use the supplied hardware. Use *Blue Loctite* on all bolts.

Parts List:

21" Steel Fender
2 pcs. 5/16 x 1" NC Bolts

3. Replace Wheel and Tire. reinstall the Brake caliper. Note: Use all Factory Torque Specs. as per HD manual.



Heartland USA
2466 E. Fender Ave. Suite B
Fullerton CA. 92831
310-822-2697 Fax 310-634-1271
www.heartlandbiker.com