

# ***ADDICTIVE DESERT DESIGNS***

## **2007.5 - 2014 CURRENT CHEVY 2500-3500 HONEYBADGER FRONT BUMPER INSTALLATION INSTRUCTIONS**

### **PREPARATION STEPS**

1. Set emergency brake.
2. You will need the following tools:
  - a. 21 mm Wrench and Socket
  - b. Ratchet or Air Gun

*Note: This installation requires 2 people for best results*

3. Included in Kit:
  - a. HoneyBadger Front Bumper



## INSTALLATION INSTRUCTIONS

1. Remove stock bumper.
2. If you have purchased a light bar to place on your bumper, install them on your bumper at this time.
3. With the help of another person loosely install bumper onto truck using factory hardware.



4. Place supplied shims into place if needed.



5. Align bumper and tighten into place.

6. Stand back and enjoy your A.D.D. HoneyBadger Front Bumper!



For additional support or technical questions,  
please call 480.671.0820 or  
email [info@addictivedesertdesigns.com](mailto:info@addictivedesertdesigns.com)

**ADDICTIVE DESERT DESIGNS**  
4840 E. JASMINE STREET SUITE 112  
MESA, AZ 85205  
[WWW.ADDICTIVEDESERTDESIGNS.COM](http://WWW.ADDICTIVEDESERTDESIGNS.COM)

