

Product Number: GR1010 Application: 2007- 2016

SAFETY

Your safety and the safety of others is very important.

- In order to help you make informed decisions about safety, we have provided installation instructions and other information.
- These instructions alert you to potential hazards that could hurt you or others.
- Please do a job safety analysis (JSA) before each task to identify potential hazards for your situation and remove/protect against them.
- You must use your own good judgment, and take your time.

Read and understand all safety precautions and instructions before installing this product.

THIS PRODUCT IS FOR OFFROAD USE ONLY. ALL LIABILITY FOR INSTALLATION AND USE RESTS WITH THE OWNER.

CARELESS INSTALLATION AND OPERATION CAN RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE.

Injury hazard

Failure to observe these instructions could lead to severe injury or death.

Always remove jewelry and wear eye protection.		
Always use extreme caution when jacking up a vehicle for work. Set emergen		
brake and use tire blocks. Locate and use the vehicle manufacturers designated		
lifting points. Use jack stands.		
Always use appropriate and adequate care in lifting components into place.		
Always insure components will remain secure during installation and operation		
Always wear safety glasses when installing this kit. A drilling operation will		
cause flying metal chips. Flying chips can cause serious eye injury.		
Always use extreme caution when drilling on a vehicle. Thoroughly inspect the		
area to be drilled (on both sides of material) prior to drilling, and relocate any		
objects that may be damaged.		
Always use extreme caution when cutting and trimming during fitting.		
Always tighten all nuts and bolts securely per installation instructions.		
Always route electrical cables carefully. Avoid moving parts, components that		
become hot and rough or sharp edges.		
Always insulate and protect all exposed wiring and electrical terminals.		
Always perform regular inspections and maintenance on mounts and related		
hardware.		






Product Number: GR1010 Application: 2007- 2016

I. Overview

Congratulations on your new purchase of the industries' best and only Jeep JK front Full Width Grumper! This Full Width Grumper has been **engineered** for strength while reducing weight.

Your Full Width Grumper was designed, CNC laser cut, fabricated, and powder coated... all in the U.S.A.

Enjoy the fit and finish of a quality JK front Full Width Grumper from Fab Fours Inc!







Product Number: GR1010 Application: 2007- 2016

II. Tools Required

- ☐ Flat Head Screwdriver
- ☐ Phillips Screwdriver
- ☐ Socket Wrench With Extension
- □ 18mm & 19mm Sockets
- □ 3/4", 1/2" Sockets
- ☐ ¾" Deep Socket

- **□** 9/16" Drill Bit
- □ 7/16" Open End Wrench
- ☐ Plastic Rivet "Christmas Tree" Removal Tool
- □ 3/16" Allen Wrench
- □ 5/32" Allen Wrench

III. Vehicle Preparation

- 1. Remove (4) dart clips from underside of OEM grille/skid plate.
- 2. Remove (2) dart clips from back side of plastic skid plate.
- 3. Disconnect fog light harness from back of each fog lamp (if applicable).

4. Remove (8) nuts from studs using 18mm socket. (Ref. Figure 1)




Figure 1





Product Number: GR1010 Application: 2007- 2016

- 5. Slide bumper forward slightly so that the studs still pass through frame but the bumper rocks forward. Remove fog harness retainer clips from bumper.
- 6. Remove OEM bumper and set aside. (Ref. Figure 2)



Figure 2

7. Remove two dart clips from top bumper trim plastic using Phillips screwdriver. Set trim aside as it will not be re-used. (Ref. Figure 3)





Product Number: GR1010 Application: 2007- 2016




Figure 3

8. Remove the turn signal from the back side of grille, this is done by rotating and pulling light out. (Ref. Figure 4)



Figure 4





Product Number: GR1010 Application: 2007- 2016

9. Opening the hood, locate and remove the push pins at the top of the grille as shown in Figure 5.




Figure 5





Product Number: GR1010 Application: 2007- 2016

10.At this point there are several clips at the base of the grille. Pulling firmly at this location the grille should now be free. (Ref. Figure 6)







Product Number: GR1010 Application: 2007- 2016

IV. Grumper Preparation

- 1. Remove the Grumper from the shipping carton. Lay all items out on a non-scratch surface to prevent damage to the powder coating.
- 2. Using the 5/16" fasteners, install the headlight inserts, grille, and logo backer plates. (Ref. Figures 7 & 8)




Figure 7




Figure 8





Product Number: GR1010 Application: 2007- 2016

If installing winch, do so now. Follow instructions provided with winch. Remember to install fairlead onto front of Grumper.

- **3.** At this point, wire provided turn signals and confirm they work before disconnecting and installing them into Fab Fours Grumper.
- **4.** Follow the wiring diagram below. It is strongly recommended a multimeter or its equivalent is used to confirm wiring before splicing.

WIRE COLORS:

TURN SIGNALS (Ref. Figures 11a-11b)


WIRE	FAB FOURS	OEM COLOR
High/Turn/Stop	Red ——	White/Pink (RH) White/Grey (LH)
Low/marker/clearance	Black ———	White/Tan (RH) White/Green (LH
Ground	White ——	Black (RH) Black (LH)





Product Number: GR1010 Application: 2007- 2016

Resistor wiring diagram



Grumper Installation

- 1. Using a 9/16" bit, drill out the top outboard holes in the frame.
- 2. Lift Grumper and align mounting studs with holes in frame face plate (ref. figure 9).





Product Number: GR1010 Application: 2007- 2016




Figure 9


- 3. Secure loosely with supplied ½" bolts, flat washers, lock washer and nut. Do not tighten fully.
- **4.** Because of the mounting system, little adjustment is necessary. Verify proper alignment and tighten all fasteners; for outer bolts reach behind wings to access frame (ref. figure 10a) and for inner bolts reach through access slot on lower guard of grumper (ref. figure 10b). A deep ³/₄" socket w/ a ratchet wrench is recommended.





Installation Instructions Jeep JK Front Grumper Product Number: GR1010

Application: 2007-2016






Figure 10a (inside view of frame outer)

Figure 10b (inside view of frame outer)



Page 12 of 13 GR1000 Copyright 2011 Fab Fours, Inc.



Product Number: GR1010 Application: 2007- 2016


V. Maintenance/Care

- ☐ Periodically check and tighten all fasteners.
- ☐ Stripped, fractured, or bent bolts or nuts need to be replaced.

VI. Contact Information

Fab Fours Inc. Phone (866)-385-1905 1312 Camp Creek Rd. Fax (866)-574-1424

Lancaster, SC 29720 Email Support@fabfours.com



More than expected... Better than expected

