



1.877.287.8634

INSTALLATION INSTRUCTIONS

IMPORTANT NOTICE: Be sure to inspect and test fit product before having it coated or painted. Ranch Hand will not be responsible for the cost of the coating if any problems with fit or finish are not noted and addressed beforehand.

PARKING SENSOR RELOCATION BAR for:

GGC16HBL1 / GGG16HBL1 / GGC14HBL1S

PART # PSC16HBL1

1. Remove the center two sensors and sensor holders.
2. Install the sensor relocation bar to the four 3/8” square holes in the uprights of the grill guard. Use the 3/8” black carriage bolts, washers and nuts to install.
3. Install the factory sensor brackets into the relocation bar.
4. Run the pigtailed through the bumper sensor hole.
5. Before installing the grommet in the holes of the bumper, cut a slit in the grommet. Slide the grommets into the holes.
6. Install the sensors in the sensor holders and plug them in.
7. Check to make sure the sensors work properly. If sensors do not, tilt the relocation bracket up or down until they work then tighten carriage bolts.
8. You may want to use a little silicon to help hold the sensor bracket into place.
9. *MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!*

----- **WARNING** -----

Special care should be exercised in the handling, storage and installation of Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment. Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.

Rev. 2021