

Access Panel Installation Instructions

Step 1. Unpack your kit. Each Kevko access panel kit should include (1) Access Panel tabbed to the outside perimeter, (1) Hinge, (1) Front Backing Plate, (1) Dzus Fastener, (1) Dzus Spring, & (4) 1/8" Pop Rivets.

Step 2. Remove the outside perimeter from the access panel. Locate the position you would like to install your panel and use the outside perimeter as the template for your rivet locations and your cutout. We recommend leaving a corner gusset when trimming to fit. (See Images Below) This will give the panel a pad to rest on. (Note: Trim 1/8" behind your traced cut line, this will cover any sharp edges once the panel is installed.)

Step 3. Now that your hole is cut, use both the access panel and the outside perimeter as your guide to drill your hinge. Be sure your hinge is as square as possible and drill with a 3/16" drill bit.

Step 4. You are now ready to install the access panel to the car. Install using 3/16" rivets. (Note: Your hinge and backing plate will install under your aluminum and sandwich it.)

Step 5. Install your dzus fastener and spring with the supplied 1/8" rivets.



Proudly made in the USA Since 1986