

I've been restoring plaster for more than 30 years.

When I needed a product that took half the time and lasted forever, I had to make it myself.

~Rory Brennan



PLASTER MAGIC[®]

FOR THE ULTIMATE PLASTER REPAIR[®]

100% MADE IN THE USA

**EASY TO USE
FIXES WALLS & CEILINGS
IN HALF THE TIME**

Plaster Magic is the only product that delivers as promised, permanently repairing cracked and loose plaster on wood lath or brick.



Type of Repair	Homeowners Pack	Painters Pack	Contractors Pack
Loose Crack	9 Lineal Feet	18 Lineal Feet	45 Lineal Feet
Loose Plaster	30 Square Feet	60 Square Feet	160 Square Feet



Find Products, Helpful Videos & Repair Tips at
WWW.PLASTERMAGIC.COM

YOU CAN DO THIS[®] Designed to help ANYONE make fast and easy professional-grade repairs, Plaster Magic is ideal for DIYers tackling small jobs as well as contractors restoring larger buildings. Three sizes of repair kits ensure you have exactly the right amount of plaster "magic" for every job!

STABILIZE WALLS & CEILINGS IN 4 SIMPLE STEPS!



1 DRILL IT

- Drill holes with a 3/16" masonry bit about 1" to 2" from the crack. When you hit the lath, stop and drill another hole about 3" away. Continue along both sides of the crack.
- For loose or bulging plaster, space the holes evenly across the area, 3" to 4" apart.
- Vacuum plaster dust from holes.



2 SPRAY IT

- Adjust the sprayer nozzle tip to the stream setting. Apply three to five pumps of conditioner into each hole.
- Wipe the excess with a wet sponge and wait 10 minutes for the conditioner to soak in.
- Clean sprayer nozzle after use to prevent clogging: Remove sprayer nozzle from bottle, flush with clean water. Replace top on bottle.



3 GLUE IT

- Trim the tip of the adhesive tube close to the end so it fits securely into the drill holes.
- Apply one squeeze per hole by gently pulling the trigger of the adhesive gun until a little comes back out. No need to fill any hole that missed a lath.
- Wipe away the excess with a wet sponge.



4 CLAMP IT

- Screw the plaster clamps into some of the existing holes on each side of the crack, every 8" to 12". Screwing in the clamps will draw the plaster and lath into "soft" contact with the adhesive.
- Wipe away excess adhesive on the surface with a wet sponge.
- Allow to dry 24 to 48 hours.
- Unscrew the clamps and remove them with a putty knife.

PLASTER MAGIC®

FOR THE ULTIMATE PLASTER REPAIR™

NEED HELP? VISIT
WWW.PLASTERMAGIC.COM

Protected by Patent Numbers US: 8,362,135 B2; 8,460,506 B1
Canada: 2617387 • AU: 2006275388 • EU: EP 1 920 022 B1

© 2014 BWA, Inc. All Rights Reserved.

Each repair kit includes conditioner, adhesive, clamps, screws & disposable gloves.

SIMPLE TOOLS NEEDED



CAUTION

- Use in accordance with directions
- Contact with professional-grade adhesive may ruin clothing and architectural finishes
- Avoid skin and eye contact. Wear waterproof gloves and eye protection. In case of eye contact, flush with water for 15 minutes, call a physician.
- Provide proper ventilation
- Protect surrounding areas
- May be harmful if swallowed
- Keep out of reach of children and pets
- Keep from freezing

ALL THAT'S LEFT TO DO:

Apply, all-purpose ready-mix joint compound to all the cracks and holes. Prime and paint, or finish as desired.

You've restored your plaster permanently, in half the time and with less effort and mess than other methods.