

How To Build a Roof: Applying Roof Adhesive with Roll Roofing

APPLYING COLD PROCESS & LAP CEMENT



- Once initial layer of 15# or 30# roofing paper is in place, install second layer using Cold Process & Lap Cement.
- Use adhesive under entire roll and between overlaps to bond together layers of paper.
- When applying roofing paper, start at the lowest point on the roof.
- Roll the paper across the roof horizontally and work a way to the top of the roof.
- Overlap paper no less than 4 inches and up to 24 inches depending on system instructions.
- Apply mineral surface roofing in same manner.

BLIND NAIL APPLICATIONS



Corrugated roofing sheets are often nailed into place leaving a path for water to leak through.

Cover these nail spots with Cold Process & Lap Cement.



When completing a cap of shingles, the last cap will have exposed nail heads which need to be covered with Cold Process & Lap Cement.