

How to seal skylights, vents, chimneys & other roof projections

USING CLEAR LEAK STOPPER™ TO CREATE AN INVISIBLE WATERPROOF SEAL



1. Apply Clear Leak Stopper as you would a latex sealant. Do not apply if rain or temperatures colder than 40°F are expected within 24 hours.
2. Prepare the surface by removing any dirt, leaves, dust, grime, sap, oil, mold/mildew, or other contaminants.
3. Cut the tube at a 45° angle to create an applicator tip. Cut tip to create a 1/8" to 3/8" bead. Remember sealants shrink when drying due to evaporation.
4. With a caulk gun apply a continuous, even bead. Hold the gun at a 45° angle and pull toward you, pushing caulk into the gap.
5. Smooth or "tool" the bead to a concave shape using a caulk finishing tool or wet fingertip. Be careful only to shape the bead—not remove it!

SEALING AND WATERPROOFING OTHER ROOF PROJECTIONS

1. Apply roof cement at base of projection. Spread the cement around the repair.
2. Embed fiberglass fabric into the cement directly over repair area to strengthen the repair.



3. Apply additional **Gardner™** or **BlackJack®** brand roof cement over fabric to completely seal the repair.

