

ASSEMBLY INSTRUCTIONS



1. Place table top face-down onto a non-damaging surface such as cardboard.

NOTE: All COMPCOR tops are machined to accommodate elevator bolts that are easily adjustable to align with holes in Oak Street spiders.





2. Insert included elevator bolts, thread-side up, into rails.



3. Place table base onto table top so all bolts in table top go through inner corner holes in spider. Put included lock washers & nuts onto bolts then tighten until snug.



4. Screw out short bolt in bottom of tube/spider.



Using socket set or crescent wrench, screw in short bolt with lock washer and flat washer into tube.





7. Locate leveling glides and screw into welded end tabs of foot.

