



# INSTALLATION GUIDE

## LED SIDE MARKERS

### PORSCHE 996 / 986

#### FITMENT

- 1999 - 2005 Porsche 911 (Carrera / C4S / Turbo / GT2 / GT3)
- 2000 - 2004 Porsche Boxster / Boxster S

#### TECHNICAL HELP

If you need technical assistance or help with the installation procedure, please email [info@flat6motorsports.com](mailto:info@flat6motorsports.com) for immediate help.

#### IN THE BOX

- 1X Driver's Side LED Marker Light
- 1X Passenger's Side LED Marker Light



#### TOOLS NEEDED

- Flat-Head Screwdriver



- 1) Begin on either the driver's or passenger's side of the vehicle. It is helpful to turn the steering wheel inward to allow for more access to the side marker.



- 2) Pull back the fender liner opening and use a flat-head screwdriver and push in the silver release tab to release the side marker. It's helpful to use one hand to pry and one hand to help pull the side marker loose. The side marker will release out with a simple press of the release.



- 3) Press the metal retaining clip inward to release the bulb from the side marker housing. Then remove the halogen bulb from the socket by pulling straight outward.



- 4) With the bulb removed, plug the LED harness into the bulb socket. Ensure the connection is made firmly and test before reinserting the side marker into the bumper cutout.



- 5) Follow the same procedure on the other side.

Installation of the LED Side Markers is now complete. Make sure to test the lights by putting the lighting on before driving the vehicle.

#### ENJOY THE PRODUCT?

Please share your experience, pictures and videos to Rennlist, 6 Speed Online, and social media! Tag us with @flat6motorsports or #flat6motorsports for a chance to win a gift card or a free product giveaway.