



INSTALLATION GUIDE

LED SIDE MARKERS

PORSCHE 997 / 987

FITMENT

- 2005 - 2012 Porsche 911 (Carrera / Carrera S / Carrera GTS / Turbo / GT3)
- 2005 - 2012 Porsche Boxster / Boxster S
- 2006 - 2012 Porsche Cayman / Cayman S / Cayman R

TECHNICAL HELP

If you need technical assistance or help with the installation procedure, please email info@flat6motorsports.com for immediate help.

IN THE BOX

- 1X Driver's Side LED Marker Light w/ Resistor
- 1X Passenger's Side LED Marker Light w/ Resistor



TOOLS NEEDED

- Flat-Head Screwdriver



- 1) Begin on either the driver's or passenger's side of the vehicle. It is helpful to turn the steering wheel inward to allow for more access to the side marker.



- 2) Pull back the fender liner opening and use a flat-head screwdriver and push in the silver release tab to release the side marker. It's helpful to use one hand to pry and one hand to help pull the side marker loose. The side marker will release out with a simple press of the release.



- 3) With the OEM side marker removed, plug in the LED Side Marker to the harness and feed the resistor down into the hole inside of the bumper. Insert the LED Side Marker into the mounting points starting at the front of the light and snap in the rear.



4) Follow the same procedure on the other side.

Installation of the LED Side Markers is now complete. Make sure to test the lights by putting the lighting on before driving the vehicle.

ENJOY THE PRODUCT?

Please share your experience, pictures and videos to Rennlist, Planet-9, and social media! Tag us with @flat6motorsports or #flat6motorsports for a chance to win a gift card or a free product giveaway.