



Contact: (509) 585-0900 / Sales@Kaizenspeed.com

## KAI-3000

### Bolt-In Mounts For TRZ Pinto Rack for C6 Factory Crossmember

---



This kit is intended for use with the TRZ-Motorsports “C5-C6 Specific Length - Pinto Rack” for the C6 Corvette. We used their complete rack kit which includes the steering shaft, u-joints, and tie rods with various spacers. The steering shaft will need to be cut and fitted by you.

\*In our application we also use a flange bearing at the firewall (Part Number: ALL52130 from Allstar Performance)

#### **Installation:**

- 1: Remove the factory steering rack, steering shaft (remove from under the dash), pump, reservoir and all power steering lines.
2. Install the primary mount in the OEM driver side subframe location using the OEM bolt and nut, then secure the two included M8 fasteners at the ABS mounting location. Tighten these fasteners.
3. Secure the manual rack to the primary mount with the provided M10 bolts, **leave loose for now.**

4. Open the clasp on the secondary mount and set the rack in the mount. (See picture for location of this mount)
5. With the mount flush against the top and front face of the crossmember, mark the three holes. Drill holes using 21/64" drill bit.
6. Secure all the provided fasteners on both mounts and make sure the rack is secure. \* DO NOT use an impact on the M6 allen-head bolt.

**REFERENCE PHOTOS:**





