

Instructions

Stand Off Cover (for Split roof hot house)



Kit comprises: Cover, Stand off brackets, self drilling screws, galvanized round pipes, bungee straps, stainless steel hooks and cable ties.

Tools required: Cordless drill with Phillips head driver & a ladder.

Directions:

1. Using the self drilling screws carefully attach the stand off brackets onto both ends of the house frame as pictured.
2. Fasten stainless steel hooks to the bottom of each steel rib with the self drilling screws
3. Slide pipes into the stand off brackets and secure in place by drilling a screw into the pre drilled hole at each end.
4. Hook bungee straps through the eyelets on the cover
5. Place the cover over the pipes and fasten the bungee straps to the stainless steel hooks.
6. When the cover has been fitted, place cable ties around the ends of the pipes and through the cover to keep it in place.