

Hello Bike Shop or Bike Expert,

Your friend/customer/acquaintance wants to turn their bike into a cargo bike. The ARGO Cargo kit is an easy way to get their.

We recommended that the bike in question gets looked over prior to deciding about converting it into a cargo bike. Check the list and let your customer know if they have a good candidate for the ARGO.

BEST PRACTICES

Your bike should work well if all of the following things are true:

It is in good working condition without safety issues

It is has standard 68 or 73mm English bottom bracket

It is made of steel or aluminum (even though other materials can be plenty strong)

It has a rigid or locking (suspension) fork

It has cable actuated brakes*

It has wheels that are 26", 27.5" (650b), 700c or 29"

It has a head angle between 69 and 73 degrees

NO SRAM Road cranks (SRAM Mountain cranks are okay on 68mm frame widths)

*For hydraulic disc brakes, a lever will need to be attached to your bar at the time of attaching your cargo kit. It will add about a minute to the installation time, but it is very easy and simple.

If you need to contact us, either email argobikes@gmail.com or call +1-720-600-2746.

Thank you for your help!

The ARGO Team