



Bar Stumps™

Wood Bar Plugs

ridepdw.com | 503-234-7257
3625 SE 21st Ave
Portland, OR 97202



Your ride is going to look REAL good with these Bar Stumps™.
Installation is simple, just jam them into the ends of your handlebars.
Read these notes First though:

- There are 3 different diameters of rubber o-ring sets included. Start with the largest diameter, as the tightest fit is the best fit.
- Need to take o-rings off to swap for a different size? If your fingernails are not of the long variety, use the end of a paper clip, fork tine, etc. to get under the o-ring and slip it off.
- If the plugs are still loose using the largest diameter o-rings don't despair! Just wrap cloth tape, or electrical tape around the plugs until they fit snugly.
- For drop handlebars, always fold the end of your bar tape into the end of your handlebars before inserting the plugs.