

Bus Fit Out



Legend

1. VENTURELITE[®]2050 0.5MM aluminium reinforced sheet with Snowflake decorative laminates. 10mm
2. ACP131 End Cap 10mm
3. ACP8587 Cabinet Door Jamb 10mm or ACP81567 Cabinet Door Jamb with Retainer 10mm
4. ACP1432 Ext Corner 10mm
5. ACP1434 Int Corner 10mm
6. ACP83217 Cornerpost 10mm
7. ACP1603 3 Way Joiner

Fabrication

VENTURELITE[®] 2050 can be easily cut and drilled with standard tools for laminate-faced boards, such as circular saws, routers, etc. Negative rake blades are recommended for circular saws.

Components and complete interiors can be fabricated using VENTURELITE[®] Profiles & Assembly Accessories, cutters and polyurethane paste adhesives.

Additional Information

Sikaflex 291 is used to bond panels and extrusions.