

Caravan Fit Out



Legend

1. VENTURLITE[®] 2050 0.5mm aluminium reinforced sheet with Wild Pear decorative laminates 20mm
2. ACP83108 Corner Post 20mm
3. ACP80360 End Cap 20mm
4. ACP2850 Cabinet Door Jamb 20mm or ACP81566 Cabinet Door jamb with Retainer 20mm
5. ACP1532A Ext Corner 20mm
6. ACP1534 Int Corner 20mm
7. ACP82896 H Joiner Shallow 20mm

Fabrication

VENTURELITE[®] 2050 can be easily cut and drilled with standard tools for laminate-faced boards, such as circular saws, routers, etc. Negative rake blades are recommended for circular saws.

Components and complete interiors can be fabricated using VENTURELITE[®] Profiles & Assembly Accessories, cutters and polyurethane paste adhesives.

Additional Information

Sikaflex 291 is used to bond panels and extrusions.