



SPYDER
INDUSTRIES



Spyder Series Headache Rack Installation Instructions

(Dodge with RAM Box)

Your installation kit consists of two-piece bed rails and mounting hardware (Fig. 1)

- A) (6) 3/8"x3/4" and (2) 3/8"x 1-1/4" bed rail assembly to rack bolts, nuts, washers
- B) (4) 5/8"x 1-1/2" and (2) 3/8"x1-3/4" L-Bracket to truck bed track & bed rail bolts, nuts, washers
- C) (2) 7/16"x1-1/4" bed rail to bed cap bolts, nuts, washers

- 1) Slide the heads of (2) 5/8" bolts into the bed track horizontally. They'll point to the center of the truck bed and serve as studs. Slide the head of a single 3/8" bolt into the upper track slot vertically so that it points up. It will serve as a stud. Place the L-Shaped bracket over the large 'studs' in the track and secure loosely with nuts and washers (Fig. 2)
- 2) Set the gusseted main section of bed rail on the corner of the truck bed over the vertical 'stud'. You may temporarily join the two brackets together with a nut and bolt while positioning the assembly (Fig. 3).
- 3) Using a helper, temporarily set the rack into the bed rail assemblies to check width. Adjust rails as necessary. Remove the rack and, using the bracket as a template, drill a 7/16" hole through the bed cap. Reach between the cab and bed under the lip to secure with nuts and washers (Fig. 4).
- 4) Tighten the fasteners associated with the bed rail assembly and track.
- 5) Carefully set the rack back into the bed rails. Use the 3/8" fasteners and flat washers (Section A of Fig. 1) to secure the rack to the bed rail assemblies (Fig. 5)
- 6) Be sure to check that all fasteners properly tightened. Enjoy!



Fig. 1




Fig. 2



Fig. 3



Fig. 4



Fig. 5