



Camaro 16-20 SS Wicker Bill Install (Also SS Wide and 19-20 SS w/ rearview active camera)

Note: Perform the following steps with the Wickers Bills plastic coating still on the wicker bill.



Camaro SS



Camaro SS Wide

- Align the wicker bill center hole to the center of the spoiler both vertically and horizontally and mark your center hole
 - Drill a 11/64 hole and bolt the sub wicker on that marking (*Drill bit provided*)
 - With the sub wicker bolted to the spoiler, align and mark the remaining holes
 - Remove the wicker and drill out the remaining marked holes
 - Remove plastic protective covering and now bolt the wicker bill to your spoiler.

If you have any questions or need additional information please email: info@zl1addons.com or give us a call M-F 7:30AM-1:30PM PT. 858 527 8727