

Veriflame to LME7 Cross Reference



Eclipse Veriflame				SCC LME7 Flame Controller Part Number
Veriflame Part Number	Purge/ No-purge/ Modulation	*UV/ FR/ IR	Voltage	
VF5602-22AA	Purge	UV	110Vac	LME71.111A1PKG
VF5602-23AA	Purge	FR	110Vac	LME71.111A1PKG
VF5602-27AA	Purge	IR	110Vac	N/A
VF5602-32AA	No-purge	UV	110Vac	LME71.112A1PKG
VF5602-33AA	No-purge	FR	110Vac	LME71.112A1PKG
VF5602-37AA	No-purge	IR	110Vac	N/A
VF5602-42AA	Modulation	UV	110Vac	LME73.812A1PKG
VF5602-43AA	Modulation	FR	110Vac	LME73.812A1PKG
VF5602-47AA	Modulation	IR	110Vac	N/A
VF5603-22AA	Purge	UV	230Vac	LME71.111A2PKG
VF5603-23AA	Purge	FR	230Vac	LME71.111A2PKG
VF5603-27AA	Purge	IR	230Vac	N/A
VF5603-32AA	No-purge	UV	230Vac	LME71.112A2PKG
VF5603-33AA	No-purge	FR	230Vac	LME71.112A2PKG
VF5603-37AA	No-purge	IR	230Vac	N/A
VF5603-42AA	Modulation	UV	230Vac	LME73.812A2PKG
VF5603-43AA	Modulation	FR	230Vac	LME73.812A2PKG
VF5603-47AA	Modulation	IR	230Vac	N/A
VF5605-22AA	Purge	UV	110Vac	LME71.111A1PKG
VF5605-23AA	Purge	FR	110Vac	LME71.111A1PKG
VF5605-27AA	Purge	IR	110Vac	N/A
VF5605-32AA	No-purge	UV	110Vac	LME71.112A1PKG
VF5605-33AA	No-purge	FR	110Vac	LME71.112A1PKG
VF5605-37AA	No-purge	IR	110Vac	N/A

For applications requiring self-checking UV scanner, use LME75.811A1PKG

See LME7 Direct Replacement Wiring Diagrams below