

**SHiFTWORKS®**

**S500**



Rear of Car



Front of Car



Note: The two brass rivets that attach the back-up light blades are the internal contacts. Align tab as shown for reverse.


1964-67 Chevelle

1965-67 Nova

1964-67 Impala

Note: 1964 Original switch had a small wire harness attached, but these switches can be used

© 2023 SHiFTWORKS®

 **WARNING: Cancer -**  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)