



www.shiftworks.com

Las Vegas, Nevada

#S522 Neutral Safety/Backup Switch 1967 Camaro & Firebird & 1968-72 Nova

This switch mounts to the inside of the shifter and is activated by a Tab (Shiftworks part #657) attached to the handle shaft.

The Template is a guide for locating the mounting screws for the switch. Cut out the Template and center it on the Hub inside the shifter. Use 10-24 or 10-32 screws or self-threading screws. Adjust the switch first for backup lights, and then refine the adjustment, if necessary, for Park-Neutral safety starting.

PURPLE WIRES – Neutral Safety

PINK & GREEN WIRES – Backup Lights

Use this switch for all Turbohydromatic 3-speed and overdrive automatic transmissions. Replaces Powerglide switches. Provides mounting plate that accommodates conversions.

